

Operating instructions digital max-min thermometer
indoor/outdoor no. 29570 Kat.no. 30.1020

The digital max-min thermometer is an electronic precision measuring instrument to determine indoor and outdoor temperature as well as the respective maximum and minimum temperatures

measuring range: outside -50 °C/+60 °C (-58 F/+140 F)

inside: -10 °C/+50 °C (+14 F/+122 F)

It is possible to change the reading from Celcius to Fahrenheit by moving a switch at the back of the instrument.

Installation:

The thermometer should be positioned near a window using the built-in hanging slot with a nail or screw. Lead the cable together with the sensing element through the window sealing material to the outside. (Take care of sharp edged window frames without seals).

Operation:

A. Top display

- 1 The thermometer shows the present outdoor temperature.
2. When pushing the 'max-min' button, the maximum temperature appears which has been reached since the last resetting
3. Pushing the 'max-min' button again, the minimum temperature appears which has been reached since the last resetting
4. To recall the present outdoor temperature on the display again, push the 'max-min' button once more
5. Now reset the max-min memory to the present temperature using the reset button.

B. Lower display

1. Show you the present indoor temperature.
- 2-5. As described under 'A', you can recall indoor maximum and minimum temperatures and reset the memory.

PLEASE DELIVER USED BATTERIES TO THE SPECIAL COLLECTING POINTS.
NO GUARANTEE IF THE INSTRUMENT IS HANDLED OR OPENED
IMPROPERLY!